

SI7500

Using a USB Flash-memory stick to store measurement data

Configuring the SI7500:

> Set the “Report” or “Send” parameters on the SI7500 as required (see the SI7500 User Manual 502823).

> Select the RS232 menu from the Setup menu.

> Select the Data field and select “None” with the appropriate softkey.

> Select the USB menu from the Setup menu.

> Select the Data field and select the desired option with the appropriate softkey. Note: “Both” will enable both Report and Send output types.

> Select the Destination field and select the “File” option to enabling saving of outputs (in Report or Send format) to the root directory of a connected USB key.

> When prompted, the SI7500 will now save any data outputs to the root directory of a connected USB flash memory stick.